



klipxtreme

# Magnifik Wireless Duo

Wireless ergonomic keyboard and mouse duo

KBK-520

## Quick function guide

The multimedia keys control different functions.



Key	Function
1. E-mail	Activates the preset e-mail application
2. Home	Provides access to the previously selected internet browser's main page
3. Next web page	Reloads a previously visited web page before activating the previous web page function
4. Previous web page	Returns to a previously visited web page
5. Search	Opens a search window to find files, folders, applications, configurations, and websites
6. Refresh	The browser shows the most updated version of the page you are viewing
7. Favorites	Contains shortcuts to folders you frequently use
8. Play/pause	Activates or stops audio playing coming from musical media or videos. This key doesn't work unless audio is played
9. Previous track	Plays the track before the present selection
10. Next track	Plays the next track of the present selection
11. Stop	Stops playing audio from musical or video media. This key doesn't work unless audio is played
12. My computer	Opens the 'my computer' directory
13. Volume down	Decreases the volume level in the computer
14. Volume up	Increases the volume level in the computer
15. Mute	Mutes computer's main volume. Press it again to restore audio
16. Media player	Activates the preset media player
17. Sleep mode	The computer enters the sleep mode
18. Wake up mode	Reactivates the computer after sleep mode
19. Power	Turns the computer on and off
20. Calculator	Allows to use the calculator

## LED indicator

Low battery  
Number lock  
Caps lock

## Scrolling wheel

Use the scrolling wheel to easily move through a document or web page. This wheel does not replace the mouse's function. The wheel will work if the cursor is placed somewhere in the document or in a web page. If the cursor is located on the search bar, the moving function will be disabled.

## Mouse



1. Left button  
2. Right button

3. Scrolling wheel  
4. DPI button

5. Forward button  
6. Backward button

Español

## Guía rápida de funciones

Las teclas de acceso multimedia controlan diversas funciones.



Tecla	Función
1. Correo electrónico	Activa la aplicación de correo electrónico predeterminada
2. Inicio	Da acceso a la página de inicio desde el navegador de internet previamente seleccionado
3. Página web siguiente	Vuelve a cargar una página web previamente visitada antes de haber activado la función de página web anterior
4. Página web anterior	Vuelve a una página web previamente visitada
5. Búsqueda	Abre una ventana de búsqueda para encontrar archivos, carpetas, aplicaciones, configuraciones y sitios web
6. Actualizar	El navegador muestra la versión más actualizada de la página que está viendo
7. Favoritos	Contiene atajos a las carpetas que usa frecuentemente
8. Reproducción/pausa	Activa o detiene la reproducción de audio proveniente de medios musicales o videos. Esta tecla no funciona a menos que se esté reproduciendo audio
9. Pista anterior	Reproduce la pista anterior de la selección
10. Siguiete pista	Reproduce la siguiente pista de la selección
11. Detener	Detiene la reproducción de audio proveniente de medios musicales o videos. Esta tecla no funciona a menos que se esté reproduciendo audio
12. Mi computadora	Abre el directorio de 'mi computadora'
13. Bajar volumen	Disminuye la intensidad del volumen principal de la computadora
14. Subir volumen	Aumenta la intensidad del volumen principal de la computadora
15. Silenciar	Enmudece el volumen principal de la computadora. Oprima la tecla nuevamente para restaurar el audio
16. Reproductor de medios	Activa la aplicación del reproductor de medios predeterminada
17. Modo de reposo	Coloca la computadora en el modo de reposo
18. Modo de despertar	Reactiva la computadora luego de haber estado en el modo de reposo
19. Encendido/Apagado	Enciende o apaga la computadora
20. Calculadora	Habilita el uso de la calculadora

## Indicador LED

Batería baja

Bloqueo de números

Bloqueo de mayúsculas

## Rueda de desplazamiento

Utilice esta rueda para desplazarse fácilmente por un documento o página web. Esta rueda no reemplaza la función de desplazamiento que desempeña el mouse. La rueda funcionará siempre que el cursor esté ubicado en alguna parte del documento o página web. Si el cursor se encuentra en la barra de búsqueda la función de desplazamiento quedará inhabilitada.

## Mouse



1. Botón izquierdo

2. Botón derecho

3. Rueda de desplazamiento

4. Botón DPI

5. Botón de avanzar

6. Botón de retroceder



KlipXtreme® is a registered trademark. All rights reserved. The *Bluetooth*® word mark is a registered trademark owned by Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners. Any mention of such is only intended for identification purposes, and is not to be construed as a claim to any rights pertaining to, sponsorship by, or affiliation with, those brands. Made in China.

KlipXtreme® es marca registrada. Todos los derechos reservados. El logograma *Bluetooth*® es propiedad de Bluetooth SIG, Inc. Todas las demás marcas y nombres comerciales son propiedad de sus respectivos dueños. Cualquier mención de los mismos es por motivo de identificación solamente y por ende, no constituye reclamo alguno a ningún derecho perteneciente a, patrocinado por, ni afiliación con cualquiera de estas marcas. Fabricado en China.

[www.klipXtreme.com](http://www.klipXtreme.com)