



klipxtreme

Revolution

Dúo inalámbrico de teclado y mouse

KCK-2705

Quick function guide

The multimedia keys control different functions.



Key	Function
1. Previous web page	Returns to a previously visited web page
2. Next web page	Reloads a previously visited web page before activating the previous web page function
3. Internet	Opens the preset web browser
4. E-mail	Activates the preset e-mail application
5. Search	Opens a search window to find files, folders, applications, configurations, and websites
6. Favorites	Contains shortcuts to folders you frequently use
7. Previous track	Plays the track before the present selection
8. Play/pause	Activates or stops audio playing coming from musical media or videos. This key doesn't work unless audio is played
9. Next track	Plays the next track of the present selection
10. Volume up	Increases the volume level in the computer
11. Volume down	Decreases the volume level in the computer
12. Mute	Mutes computer's main volume. Press it again to restore audio

LED indicators

Number lock

Caps lock

Low battery

Scrolling wheel

Use the scrolling wheel to easily move through a document or web page. This wheel does not replace the mouse's function. The wheel will work if the cursor is placed somewhere in the document or in a web page. If the cursor is located on the search bar, the moving function will be disabled.



1. Left button
2. Right button
3. Scrolling wheel
4. DPI button

Guía rápida de funciones

Las teclas de acceso multimedia controlan diversas funciones.



Tecla	Función
1. Página web anterior	Vuelve a una página web previamente visitada
2. Página web siguiente	Vuelve a cargar una página web previamente visitada antes de haber activado la función de página web anterior
3. Internet	Abre el navegador web predeterminado
4. Correo electrónico	Activa la aplicación de correo electrónico predeterminada
5. Búsqueda	Abre una ventana de búsqueda para encontrar archivos, carpetas, aplicaciones, configuraciones y sitios web
6. Favoritos	Contiene atajos a las carpetas que usa frecuentemente
7. Pista anterior	Reproduce la pista anterior de la selección
8. Reproducción/pausa	Activa o detiene la reproducción de audio proveniente de medios musicales o videos. Esta tecla no funciona a menos que se esté reproduciendo audio
9. Siguiete pista	Reproduce la siguiete pista de la selección
10. Subir volumen	Aumenta la intensidad del volumen principal de la computadora
11. Bajar volumen	Disminuye la intensidad del volumen principal de la computadora
12. Silenciar	Enmudece el volumen principal de la computadora. Oprima la tecla nuevamente para restaurar el audio

Indicadores LED

Bloqueo de números

Bloqueo de mayúsculas

Batería baja

Rueda de desplazamiento

Utilice esta rueda para desplazarse fácilmente por un documento o página web.

Ésta no reemplaza la función de desplazamiento que desempeña el mouse. La rueda funcionará siempre que el cursor esté ubicado en alguna parte del documento o página web. Si el cursor se encuentra en la barra de búsqueda la función de desplazamiento quedará inhabilitada.



1. Botón izquierdo
2. Botón derecho
3. Rueda de desplazamiento
4. Botón DPI



KlipXtreme® is a registered trademark. All rights reserved. The *Bluetooth*® word mark is a registered trademark owned by Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners. Any mention of such is only intended for identification purposes, and is not to be construed as a claim to any rights pertaining to, sponsorship by, or affiliation with, those brands. Made in China.

KlipXtreme® es marca registrada. Todos los derechos reservados. El logograma *Bluetooth*® es propiedad de Bluetooth SIG, Inc. Todas las demás marcas y nombres comerciales son propiedad de sus respectivos dueños. Cualquier mención de los mismos es por motivo de identificación solamente y por ende, no constituye reclamo alguno a ningún derecho perteneciente a, patrocinado por, ni afiliación con cualquiera de estas marcas. Fabricado en China.

www.klipXtreme.com